

Eppendorf Vacufuge (Kell 405)

Every time you use the Vacufuge, you MUST sign the logbook.

Balance your tubes.

Clean up any spills in the chamber.

Contact: Sonja Young (404) 413-5363; sstovall@gsu.edu

1. Turn on power on the right back of instrument.
2. Load samples into rotor. Balance tubes. Open caps.
3. To heat while evaporating
 - a. Press set temp. button
 - b. Keep pressing button until you get to the temp. you want (30°C, 45 °C, 60 °C). The last selection is no temp. (__)
 - c. The light will keep flashing until the chamber reaches the temp. selected
 - d. The Temp. can be changed during a run
4. Press start
5. The rotation control lamp turns green. As soon as the lid has locked automatically, the Vac goes on. At 1000 rpm, the vacuum pump is switched on. The vacuum lamp lights up and the ventilation valve closes. The ventilation lamp flashes.
6. Press stop. The vacuum light goes out, when the rotor stops, the rotation lamp goes out. The lid lamp lights up when the lid can be opened.